

G120

Cellular 2G or LTE-M / NB-IoT Optional Iridium Satellite Hybrid

GPS tracking device and Bluetooth® Gateway with optional Iridium Satellite for out-of-coverage tracking with inputs/outputs, RS-232 Interface, and remote immobilization for fleet management, driver ID, driver safety and behavior monitoring, remote worker safety, theft recovery, and more





Real-Time Tracking

High-precision GPS/GLONASS tracking device wired to vehicles or equipment



Internal Backup Battery in case of loss of power or tampering

Bluetooth Gateway

Bluetooth® 5.0 Gateway for tagged asset management and sensor monitoring

իլի Inputs/Outputs

1 x Analog Input, 6 x Digital Inputs, 2 x Switched Ground Digital Outputs, 1 x Ignition Digital Input, Switched Power Out

RS-232 Interface

RS-232 Interface to connect optional Iridium Edge® Module or interface with controllers and sensors

3 Driver ID

Configure iButton®, RFID readers and Wiegand Interface for Driver ID

\ Driver Behavior

Accident and rollover detection, speeding, harsh braking, and more

\frac{1}{2} In-Cab Alerts

Built-in Buzzer for in-cab alerts

Connectivity

2G	2G: SARA-G350-02S-01	
	850/900/1800/1900 MHz	
LTE-M / NB-IoT	uBlox SARA-R410M Modem operates on all major global LTE-M and NB-IoT bands	
	Supported LTE bands:	
	1*, 2, 3, 4, 5, 8, 12, 13, 18, 19, 20, 26*, 28	
	(*roaming bands)	
Bluetooth® 5.0 Gateway	Bluetooth 5.0 gateway reports nearby Bluetooth tags and sensors for affordable tagged asset management and sensor monitoring	
SIM Size & Access	Internal Micro 3FF SIM	

Location

Module	uBlox EVA-M8	
Constellation	Concurrent GPS / GLONASS	
Channels	72 Channel High Sensitivy Receiver	
Tracking Sensitivity	-167dBM industry-leading tracking performance	
Location Accuracy	~2.0m CEP, 50%, 24 hours static, GPS, SBAS, -130dBm, > 6SVs	
GNSS Assistance	GNSS almanac data for greater sensitivity and position accuracy	
Low Noise Amplifier	GPS signals are boosted by a unique low-noise amplifier (LNA) allowing operation where other units fail	

Power

Input Voltage	8-45V DC (max)	
Self-Resetting Fuse	Built-in self-resetting fuse makes installation simple and safe. Stringent automotive power "load dump" tests are conducted to ensure operation in the harshest electrical systems.	
Operating Current	~25/50mA when moving ~150mA battery charging	
Sleep Current	<2mA	
Backup Battery	1100mAh LiPo internal backup battery pack	

Mechanics / Design

Dimensions	125 x 65 x 30 mm (4.92 x 2.56 x 1.18")	
Weight	250 g (8.82 oz)	
Housing	ABS Polycarbonate Plastic. Non-branded housing for optional white-labeling.	
Installation	24 Pin Connector provided as standard	
Operating Temperature -30°C to +60°C (connected to external power) At < 0°C and > +40°C the internal backup battery will not be charged as a safety precaut dangers associated with charging batteries at extreme temperatures.		

Mechanics / Design (continued)

Cellular Antenna	Internal	
GPS Antenna	Internal	
RF Antenna	Internal	
3-Axis Accelerometer	3-Axis Accelerometer to detect movement, high G-force events, and more	
Diagnostic LED	Diagnostic LED indicates operation status	
Flash Memory	Store weeks of records if device is out of cellular coverage. Storage capacity for over 10 days of conti uous 30-second logging	
Internal Buzzer	Internal buzzer fitted for audible alerts for speeding, harsh driving, driver ID reminders, error condition input feedback, and other events	

Interfaces

Analog Inputs	1 x O-30V Analog Inputs,	
	Auto Ranging, 12-bit ADC	
	0-5V range: 1.22mV precision	
	0-30V range: 7.32mV precision	
Digital Inputs	6 x digital inputs with configurable pull-up/down	
	0-48V DC input range	
	On/Off thresholds:	
	Pull-up enabled: low at 0.8V, high at 1.0V	
	Pull-down enabled: low at 2.0V, high at 2.4V	
Digital Outputs	2 x Switched Ground Digital Outputs	
	Easily wired up to switch external lights, relays, buzzers, etc	
	Can be used to immobilize a vehicle	
Ignition	1 x dedicated ignition digital input 0-48V DC	
	5V on/off threshold	
RS-232	Can be used to connect Iridium Edge® Module or interface with controllers and other sensors	
Switched Power Out	Outputs are either 5V (external power connected) or Vbatt (no external power) Max Current: 400mA	
	The G120 can provide power to external peripherals, eliminating the need for additional external power	
	supplies	
TTL Interface	Serial interface used to connect a Digital Matter RFID reader for Driver ID	
Wiegand	The G120's Wiegand Interface enables easy integration with a variety of RFID card types and readers.	
	Existing employee access badges or IDs can be used with a Wiegand reader for driver ID, permission-	
	based actions, and theft prevention, eliminating the hassle of issuing additional ID cards or fobs.	
1-Wire® or iButton®	1-Wire® or iButton® can be used to read Driver ID tags. Readers available to suit multiple card formats	

Smarts

Accident & Rollover Detection Driver ID Options Driver Safety & Behavior Geofence Alerts	of approximately 2 hours of data. In the event of an accident, a subset of the data (60 seconds before / 10 seconds after) is uploaded to the server automatically (if configured) or can be requested manually for a detailed reconstruction of the incident. RFID, iButton® or Wiegand interface for Driver ID, access control, and logbooking. Wiegand interface supports many third-party readers to read nearly any ID card type. Monitor speeding, harsh acceleration, braking, cornering, idling, and more to improve safety and prevent unnecessary wear on vehicles The server can use device location to create geofences and alerts if an asset enters or leaves designated locations Geofences can be downloaded directly to the device from Telematics Guru for enhanced loca-	
Driver ID Options Driver Safety & Behavior Geofence Alerts	hicle or equipment. Second-by-second GPS data is saved on the device's flash memory, with a capacity of approximately 2 hours of data. In the event of an accident, a subset of the data (60 seconds before / 10 seconds after) is uploaded to the server automatically (if configured) or can be requested manually for a detailed reconstruction of the incident. RFID, iButton® or Wiegand interface for Driver ID, access control, and logbooking. Wiegand interface supports many third-party readers to read nearly any ID card type. Monitor speeding, harsh acceleration, braking, cornering, idling, and more to improve safety and prevent unnecessary wear on vehicles The server can use device location to create geofences and alerts if an asset enters or leaves designated locations Geofences can be downloaded directly to the device from Telematics Guru for enhanced loca-	
Driver Safety & Behavior Geofence Alerts	Wiegand interface supports many third-party readers to read nearly any ID card type. Monitor speeding, harsh acceleration, braking, cornering, idling, and more to improve safety and prevent unnecessary wear on vehicles The server can use device location to create geofences and alerts if an asset enters or leaves designated locations Geofences can be downloaded directly to the device from Telematics Guru for enhanced loca-	
Geofence Alerts	vent unnecessary wear on vehicles The server can use device location to create geofences and alerts if an asset enters or leaves designated locations Geofences can be downloaded directly to the device from Telematics Guru for enhanced loca-	
	designated locations Geofences can be downloaded directly to the device from Telematics Guru for enhanced loca-	
Geofence Download to Device	·	
	Geofences can be downloaded directly to the device from Telematics Guru for enhanced location-based actions and alerts. Maximum of 750 Geofences with up to 100 points per geofence.	
GPS Jamming Detection	GPS Jamming or Interference can be detected and alerted on	
In-Vehicle Alerts	Can be wired up to external buzzers or lights for in-vehicle alerts	
Lone Worker Safety	Interface a variety of duress pendants to enable man-down alerts for lone worker safety monitoring	
	Fit the G120 with an optional Iridium Edge® Module using the RS232 connection to track assets in remote areas outside of cellular coverage	
Preventative Maintenance	Set reminders based on distance traveled and run hours to reduce maintenance and repair costs	
Real-Time Tracking	Device remains continuously connected while on the move for real-time asset tracking	
-	Interface a variety of duress pendants to enable man-down alerts for remote (out-of-coverage) worke safety monitoring *Requires Iridium Edge® Module	
	Digital outputs can be connected to a relay to enable remote immobilization of vehicles and equipmen in the case of theft, abuse, or unauthorized usage	
Run Hour Monitoring	Calculate run hours and distance traveled (odometer) to understand and optimize asset utilization	
_	Interface with a range of devices and switches for seatbelt detection, duress and panic buttons, lights, in-cab warning buzzers, and more	
Tamper Alerts	Instant alert if the device is removed from your asset or disconnected from its power source	
Theft Recovery	Switch to Recovery Mode in the case of theft or loss to activate real-time tracking for asset retrieval	

Device Management

Flexible Configuration	Configure device parameters such as position update rate, movement and accelerometer settings, and more to fit any tracking application	
Device Management Platform	Manage, monitor, configure, debug, update, and restart devices remotely from our cloud-based device management system	
Configuration App	Configurable with DMLink provisioning tool	

Integration

|--|--|

Security

Data Security	Military-level AES-256 Encryption from device to OEM Server to protect the integrity and
	confidentiality of telematics data. Data forwarded to third-party systems is sent via HTTPS for end-to-
	end security.

Warranty

Manufacturer's Warranty	Two-year manufacturer's warranty	
-------------------------	----------------------------------	--

Certifications

Please contact us for a full list of compliance specifications and documentation for your region.

LTE-M / NB-IoT - FCC, ISED, Bluetooth® Certified, CE (Doc)
2G - Bluetooth® Certified, CE (Doc)